



RY61

Remote"AG061"



- Carry out the factory settings first
- Bring the key fobs as close to each other as possible
- Press and hold the "source" key fob
- Hold down the button you want to program on the "copy" (wait until the key fob starts flashing regularly)

