



TS666

4PIN TECK SWITCH 6X6-6MM



- Current Rating : TACTILESWITCH
- This is a momentary tactile switch.
- This means that the switch will only work when it is physically hold down.
- Once pressure is release, the switch will disconnect and the action will stop.
- This switches are commonly see on household devices like a microwave's control pad to set the time and heat level when cooking food.
- This switches has high silicon rubber insulation and the handle is also build from that material.